











Assembly Sheet Tower Frame - Tower Tent

Replacement parts can be obtained from any Bolton Furniture authorized dealer

249 Professional Drive, Morrisville, VT
Phone: 802-888-7974
Fax: 802-888-3668
Web Site: www.boltonfurniture.biz

PARTS LIST

NO.	Drawing	Description	Qty.
A		Tower Post-1	1
B		Tower Post-2	1
C		Roof-1	1
D		Roof-2	1
E		Wing Nut	1
F		Flag Pole	1
G		50mm Hex Bolt	4
H		M6 Hex Wrench	1
I		Flag	1
J		Tower Tent	1

Tower Frame / Tower Tent Assembly: Two people recommended for this assembly.

Step 1


Complete Assembly of Low Loft

Step 2 -

Open boxes and verify that all parts are included.




Step 3 - Assemble Tower Frame

Attach Roof 1 & 2 (part C & D) to Tower Posts 1 & 2 (parts A & B).



Step 4 - Attach Tower Frame to Ladder





Align holes in Tower Posts to threaded inserts in back edge of ladder. Thread 50 MM Hex Bolt (G) thru tower frame holes into insert. Tighten using Hex Wrench (H)



Step 5 - Attach Tower Fabric & Flag

Place the Tower Fabric (J) over the Tower Frame.

Slide Flag Pole (F) thru Flag (I). Align holes in metal frame Roof assembly and hole in top of Tower Fabric (J). Secure flag pole to metal frame assembly using Wing Nut (E).



This completes the assembly of the Tower Frame / Tower Tent Fabric!

